



# Smart Search

**Introduction:** The DVR has a super cool feature that allows you to select an area and jump directly to when motion was detected in that area.

**Step 1:** Let's begin this part of the tutorial by opening the Search and Playback screen. Right click, then select **Search** from the on screen menu.



**Step 2:** Now let's open our **single channel view** (this will only work in single channel view), then select a **cam** channel. Once we have a channel selected begin playback by either pressing the **play** button or clicking somewhere in the **timeline**. Now that we have our recording playing back for us let's click somewhere on the video while holding the **left mouse button**, slowly drag the mouse to **draw a selection box**.



**Step 3:** Once we have an area selected click the **Smart Search** icon.



The DVR will jump straight to the next point where movement was detected inside the selection area and start playback from that point. See screenshot below. You can continue to let the motion event play or fast forward to the next motion event for that area.

From R/W HDD

REC  PIC

< Mar 2012 >

Su	Mo	Tu	We	Th	Fr	Sa
			1	2	3	
4	5	6	7	8	9	10
11	12	13	14	15	16	17
18	19	20	21	22	23	24
25	26	27	28	29	30	31

6

12:00:00 AM - 12:00:00 AM

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24

Smart Search  Synchron  All Record  Normal  Alarm  Motion